

SAVE THIS FOR YOUR RECORDS

INSTRUCTIONS FOR USE AND CARE

READ ALL INSTRUCTIONS BEFORE USING THIS FAN.


When using electrical appliances, basic safety precautions should always be followed including the following:

1. Use fan only as described in this manual. Other use not recommended may cause fire, electric shock or injury.
2. This product is intended for household use Only and not for commercial or industrial use.
3. To protect against electrical shock, do not place fan in window, immerse unit, plug or cord in water or spray with liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug fan from outlet when not in use, when moving fan from one location to another, before putting on or taking off parts and before cleaning.
6. Avoid contacting moving parts.
7. Do not operate in the presence of explosive and/or flammable fumes.
8. Do not place fan or parts near an open flame, cooking or other heating appliance.
9. Do not operate fan with a damaged cord, plug or after the fan malfunctions or has been dropped or damaged in any manner.
10. The use of attachments not recommended or sold by WeatherWorks Corporation may be hazardous.
11. Do not use outdoors.
12. Do not let cord hang over the edge of a table or counter, or let it touch

14. To disconnect, grip plug and pull from wall outlet Never yank cord.
15. Always use on a dry level surface.
16. Do not hang or mount fan on a wall or ceiling.
17. Do not operate without fan grills properly in place.
18. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT attempt to defect this safety feature.
19. SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.
WARNING To reduce the risk of fire or electrical shock, DO NOT USE THIS FAN with any SOLID STATE Speed Control Device.


FOOT ASSEMBLING **YOU MUST PUT ON THE FEET**

1. Put your fan upside down, slide foot into the slot on fan base.
2. Tighten the screw with a screw driver



OPERATION

1. Set your fan on a level and dry surface.
2. Plug the power cord into a standard 120 Volt AC wall outlet.
3. Turn the Power Knob to the desired fan speed HIGH, MEDIUM or LOW.



CARE AND CLEANING

1. Always unplug the fan before cleaning.
2. Use a soft cloth, moistened with a mild soap, to clean fan and guard. DO NOT use abrasive cleaners.
3. DO NOT immerse fan in water and never allow water to dip into the motor component.
4. DO NOT use gasoline, thinner or other chemicals to clean the fan.